

# Shunt capacitor fabrication

## Recipe for shunt capacitor fabrication in MoRe cavities

- High resistivity silicon substrate (10x10 mm), 525 micron substrate. Diced from 4 inch wafer
1. Clean dicing resist off with Acetone and IPA baths (with or without ultrasound)
  2. Optional: Clean with BHF etch (BOE 7:1) for about 1-2 minutes and stop in water. Dry from IPA to avoid dirt from drying from water.
  3. Sputter MoRe in MB-AJA:
    - 60 sccm Argon flow
    - Position mode on pressure controller
    - 100W rf power
    - Sputter rate, 60 nm in 5 minutes
  4. Coat wafer in positive e-beam resist AR-P 6200.09:
    - 4000 rpm: approximately 200 nm thickness
    - 3 min at 150C on hotplate
  5. Expose bottom layer pattern in Ebeam at 210 uC/cm<sup>2</sup> dose.
    - If features are larger than 100 nm, 250-300 uC/cm<sup>2</sup> can be used.
  6. Develop in Pentylacetate for 60 seconds and stop in MIBK:IPA 1:1
  7. Etch MoRe layer by RIE:
    - SF<sub>6</sub>/He 12.5/10 sccm, 10 ubar, 50W rf power
    - Etching time of about 1:35 min for 50 nm of MoRe
  8. Strip resist in warm PRS3000, 70C for 1-2 hours. Dry from IPA.
  9. Coat with PECVD Si<sub>3</sub>N<sub>4</sub>
    - Use PECVD Si<sub>3</sub>N<sub>4</sub>, 300C HiQuality recipe
    - 3:35 min, 50 nm approximately
  10. Coat in negative resist AR-N 7700.18:
    - 3000 rpm: approximately 450 nm thickness
    - 1 min at 90C on hotplate
  11. Expose dielectric layer pattern in Ebeam at 210 uC/cm<sup>2</sup> dose (or higher)
  12. Develop using MF321 for 60 sec, stop in MF321:H<sub>2</sub>O 1:10 for 15 seconds twice and once in water
  13. Etch Si<sub>3</sub>N<sub>4</sub> in BHF for 45 seconds (50 nm of Si<sub>3</sub>N<sub>4</sub> removed). Dry from IPA if possible
  14. Strip resist in warm PRS3000, 70C for 1-2 hours. Dry from IPA.
  15. Coat in triple layer liftoff positive Ebeam resist:
    - layer 1: PMMA 950K A7, 3000 rpm, 180C bake on hotplate for 4 minutes
    - layer 2: PMMA 450K A4, 3000 rpm, 180C bake on hotplate for 4 minutes
    - layer 3: PMMA 950K A7, 3000 rpm, 180C bake on hotplate for 4 minutes
  16. Expose top layer metal pattern in Ebeam at 1200-2400 uC/cm<sup>2</sup> dose (maybe even higher)
  17. Develop in MIBK:IPA 1:3 for 90 seconds and stop in IPA for 60 seconds.
  18. Sputter top layer of MoRe in MB-AJA
    - 60 sccm Argon flow
    - Position mode on pressure controller
    - 100W rf power
    - Sputter rate, 60 nm in 5 minutes
  19. Liftoff in warm PRS3000 (70C) preferably also using a stirrer (1-2 hrs). Blowdry after rinsing in IPA.

- This page was last modified on 15 November 2017, at 13:49.